Skillair REGULATOR

Each system served by the air supply mains (e.g. actuators and general appliances) requires its own constant operating pressure. It is necessary to use a regulator to regulate the pressure within a set range by means of regulating springs, with the pressure never exceeding the mains pressure. The new Skillair® regulator uses a rolling diaphragm which gives a much better performance than the flat version. Advantages of this system:

- Increased stroke, increased valve opening and hence higher flow rate.
- Decreased dynamic and inrush friction; prompter, more sensitive operation.
 Reduced working stress and hence longer life allowing the use of thinner
- diaphragms (0.45 mm versus 1.5 mm for a flat one) which increases regulator sensitivity and prompt action.
- Increased accuracy in maintaining the set pressure with both variable flow rates and different feed pressures. •
- Downstream overpressures relieved quickly.



TECHNICAL DATA		REG 100		REG 200			REG 300			REG 400 PILOT OPERATED*			
Threaded port		1/4″	3/8″	1/4″	3/8″	1/2″	1/2″	3/4″	1″	1″	1 1/4″	1 1/2″	2″
Setting range	bar	0 to 2 - 0 to 4 - 0 to 8 - 0 to 12							Depending on the pilot operated regulator				
Max. input pressure	MPa	1.5		1.5		1.3		1.3		1.3			
	bar	15		15		13		13		13			
	psi	217		217		188		188		188			
Flow rate at 6.3 bar (0.63 MPa to 91 psi)	Nl/min	1100		2500			3500		18000		20000		
ΔP 0.5 bar (0.05 MPa to 7 psi)	scfm	39		88		124		363		707			
Flow rate at 6.3 bar (0.63 MPa to 91 psi)	Nl/min	1600		3500		7000		-		-			
ΔP 1 bar (0.1 MPa to 14 psi)	scfm	57		124		247			-		-		
Max temperature at 1 MPa; 10 bar; 145 psi	°C	50		50		50			50		50		
	°F	13	22		122			122			122		122
Weight	kg	0	.4		0.7			1.4			4.8		5.6
Wall fixing screws		M4	x 50		M5 x 60			M5 x 70			M6 x 110)	M6 x 110
Pressure gauge port		1/	'8″		1/8″			1/8″			1/4″		1/4″
Mounting position		In any position											
Fluid		Filtered lubricated or unlubricated compressed air. Lubrication, if used, must be continuous.											
Notes on use		The regulator pressure must always be set upwards.											
		For increased sensitivity, use a pressure regulator with a rated pressure as close as possible to the required value.											
		Do not take air from pressure gauge ports.											

*Supplied without a pilot regulator.

COMPONENTS REG 100 - 200 - 300

- Technopolymer body
 Zamak end plate

- 3 Technopolymer knob
 4 Technopolymer bell
 6 OT58 brass adjusting screw
 6 OT58 brass scroll
 9 Stad adjustice of the scroll
- ⑦ Steel adjusting spring
- 8 Technopolymer ring nut
 9 Rolling diaphragm
- 10 NBR relieving gaskets
- ① OT58 brass stem
- 12 Valve with NBR vulcanized gasket
- (13) Stainless steel valve spring
- (i) Technopolymer plug
- (15) NBR gaskets



Skillair® REGULATOR

C3

C3.20



COMPONENTS REG 400 PILOT OPERATED

- Aluminium body
- 2 Aluminium end plate
 3 Anodized aluminium threaded bush, axial adjustment
 4 OT58 brass retaining ring
- 5 Rolling diaphragm
- 6 Anodized aluminium plug
- ⑦ Stainless steel valve spring
 ⑧ OT58 brass stem with air r OT58 brass stem with air relief hole
- 9 Valve with NBR vulcanized gasket
- 10 NBR gaskets



FLOW CHARTS

REG 100 1/4 - 3/8 Preset pressure Pm = 7 bar - 0.7 MPa - 100 psi psi MPa bar 10 <u>6.6</u> <u>и</u> 11.65_1





٥

Preset pressure Pm = 7 bar - 0.7 MPa - 100 psi psi MPa bar 85 6 7 45 35



1400





REG 300 1/2 - 3/4 - 1 Preset pressure Pm = 7 bar - 0.7 MPa - 100 psi psi MPa ba n 92 <u>64. p.4</u> <u>0.</u>3



REG 400 2"

Preset pressure Pm = 7 bar - 0.7 MPa - 100 psi





• Flow tests carried out at the Department of Mechanics, Turin Polytechnic, using the computerized test bench following CETOP RP50R recommendations (ISO DIS 6358-2-approved) with ISO 5167 diaphragm gauge.

UNITS

DIMENSIONS

100 - 200 - 300





	REG 100	REG 200	REG 300	REG 400				
Threaded port G	1/4″ 3/8″	1/4" 3/8" 1/2"	1/2" 3/4" 1"	1″ 11/4″ 11/2″ 2″				
A	78	93.5	110 112	225 to 255 283 to 313				
В	98	125	148	127				
С	50	63	72	118				
D	43	55	65	105				
E	63	78.5	92	141.4				
F	26	36	42	80				
Н	30 x 1.5	40 x 1.5	48 x 1.5	-				
I	21.5	27.5	32.5	52.5				
L	Hole for M4 screws	Hole for M5 screws	Hole for M5 screws	Hole for M6 screws				
Μ	43	55.5	65	105.4				
N (pressure gauge port)	1/8″	1/8″	1/8″	1/4″				
P	46	58	69	-				
R (relief)	-	-	-	1/4″				

INSTRUCTIONS FOR USE REG 400



REMOTE PILOT

- Fit the A7 M5 plug into the threaded hole (close to the entrance).
 Fit the M5 fitting into the threaded hole (as close to the entrance as possible.
- Connect the downstream circuit of the selected pilot operated regulator to the input (A) (R1 fitting).
- Set the required pressure on the pilot operated regulator.

DIRECT PILOT WITH Skillair® PILOT OPERATED REGULATOR

- Remove the pins © and © under the pilot operated regulator. • Check that the two gaskets (E) and (F) under
- the pilot are in place.
- Fix the pilot operated regulator to the base of the regulator using the self-threading screws (G). Make sure the arrows (B) point in the same direction as the arrows in relief under the base of the regulator.

UNITS

Skillair® REGULATOR

INSTRUCTIONS FOR USE REG 400

3



PILOT REGULATOR FOLLOW-UP LINK

This is used when the regulator is mounted downstream of a V3V valve or an APR. The air can be bled from the V3V or APR valves instead of from the regulator relieving system.

- Remove only the stud pin marked with a letter D under the pilot regulator.
- Check the two gaskets under the pilot marked (E) and (F).
- Secure the pilot regulator to the regulator base with the self-tapping screws marked with a letter ©. Making sure the arrows marked P point in the same direction as the arrows in relief under the regulator base.
- Remove the A7 M5 plug from the V3V or APR plate and remount the fitting.
- Connect the pilot regulator supply to the fitting.

SYNOPTIC, SIZES AND VERSIONS

REG	100	1/4	02	The pilot operated regulator is necessary
ELEMENT	SIZE	THREADED PORT	SETTING RANGE	for size 400. See page C3 .27
REG	100 200 300	1/4 <u>3/8</u> 1/4 3/8 <u>1/2</u> 1/2 3/4	02 = 0 to 2 bar 04 = 0 to 4 bar 08 = 0 to 8 bar 012 = 0 to 12 bar	
	400	1 1 1/4 1 1/2 2	Depending on the pilot used	

ORDERING CODES

Code	Description
Skillair® 100 R	EGULATOR
3202001A	REG 100 02 without end plates
3202002A	REG 100 04 without end plates
3202003A	REG 100 08 without end plates
3202004A	REG 100 012 without end plates
3202001	REG 100 1/4 02
3202002	REG 100 1/4 04
3202003	REG 100 1/4 08
3202004	REG 100 1/4 012
3302001	REG 100 3/8 02
3302002	REG 100 3/8 04
3302003	REG 100 3/8 08
3302004	REG 100 3/8 012

Code	Description
Skillair® 200 R	EGULATOR
3402001A	REG 200 02 without end plates
3402002A	REG 200 04 without end plates
3402003A	REG 200 08 without end plates
3402004A	REG 200 012 without end plates
3402001	REG 200 1/4 02
3402002	REG 200 1/4 04
3402003	REG 200 1/4 08
3402004	REG 200 1/4 012
3502001	REG 200 3/8 02
3502002	REG 200 3/8 04
3502003	REG 200 3/8 08
3502004	REG 200 3/8 012
3602001	REG 200 1/2 02
3602002	REG 200 1/2 04
3602003	REG 200 1/2 08
3602004	REG 200 1/2 012

Code	Description
Skillair® 300 R	EGULATOR
4402000A	REG 300 02 without end plates
4402001A	REG 300 04 without end plates
4402002A	REG 300 08 without end plates
4402003A	REG 300 012 without end plates
4402000	REG 300 1/2 02
4402001	REG 300 1/2 04
4402002	REG 300 1/2 08
4402003	REG 300 1/2 012
4502000	REG 300 3/4 02
4502001	REG 300 3/4 04
4502002	REG 300 3/4 08
4502003	REG 300 3/4 012
4602000	REG 300 1 02
4602001	REG 300 1 04
4602002	REG 300 1 08
4602003	REG 300 1 012
Skillair® 400 R	EGULATOR
6102001A	REG 400 without end plates
6102001	REG 400 1
6202001	REG 400 1 1/4
6302001	REG 400 1 1/2
6402001	REG 400 2

C3